

Stow on the frame: Technique for Dacron Sails

1. Remove cross tube, disconnect Y tubes, fold wing top side in with front tubes inside of sail. Lay boom alongside front tubes.



2. Stow battens, cross tube and tip wands. Stow battens so they are protected by the boom with the curved ends of battens next to curved end of boom.



3. Roll the sail, frame, battens, cross tube, and tip wands.



4. Stow in bag. (It is OK to fold the end of the sail to fit the bag.)